



## GUTTER

ACRYLIC  
ROOF  
DETAILS

SEAL

FOOT

FOR ORDER

OR

09-20-17

CHAMBERLAIN

NOTE:

A-11

### NOTES:

1. THE PRIMER APPLICATION IS REQUIRED BEFORE THE SLOPPING IS STARTED
2. NEW METAL DripEDGE OR FLASHING FLASHING NEEDS TO BE TREATED WITH EPOXY UNDERLAYER OR A PRODUCT THAT WILL REMOVE THE OILY RESIDUE BEFORE PROCEEDING TO APPLY COATING PRODUCTS OVER THE NEW METAL SURFACE.